



## GRAVITY MODULE DOWNLIGHT SERIES INSTALLTION MANUAL






Before installation:

1. The entire installation process must be installed by a qualified electrician.
2. Make sure that the luminaires and the power supply units are always disconnected from the main supply before starting the installation.  
DO NOT make connection with power ON. Keep the installation manual and follow the procedures properly.

	GR-DM1	GR-DM2	GR-DM3
ØA	68mm	100mm	150mm



0.75m<sup>2</sup> double insulation cables  
External power supply voltage input 220-240VAC



	GR-DM1	GR-DM2	GR-DM3
A	65mm	80mm	100mm

